

Some notes on the installation of your Builder's Sport Package Deck Sleeves:

- 1) The distance from the face of the Basketball Backboard to the center of the pole, which is inserted, into the deck sleeve is approximately 15". It is recommended that you install the deck sleeves ***no further*** than this distance (15") from the face of the coping to center of the sleeve. If you want the backboard to cantilever over the edge of the pool, then reduce this distance. Anywhere between 12" and 15" seems to work well.
- 2) If you're applying a secondary surface (i.e. brick or flagstone) to concrete base, be sure you leave the correct amount of sleeve exposed out of the base so that the final effect is that the top of the sleeve or cap is flush.
- 3) ***Be sure that you have set the deck sleeves plumb!!*** You might be laughing, saying to yourself "no kidding" – but we wouldn't be saying this if we hadn't seen plenty of volleyball poles which looked like the "leaning tower." The easiest way to make sure the sleeves are plumb is to insert a pole into them when they are being set and ***use your level.***
- 4) Make sure you clean the top of the sleeves and the internal threads of any cement or debris so that the caps and the lock fittings can be installed with ease.
- 5) If you have any questions, please do not hesitate to call us at 1-800-420-3255.

